



See online
technical sheet

/ TB11D

Stand for MV fuses



/ Use

For holding spare fuses kept available in MV substations or cells.

/ Technical specifications

Stand comprising 2 elements (1 upper element with 3 slots for fuses up to max. Ø 65 mm, 1 lower element with flat base).

Material: white injected thermoplastic material.

Supplied with rear holes pour for fixing to wall (supplied with fixing screws and hooks).