



See online
technical sheet

/ LW06-09 Auxiliary arm



/ Use

Attached to a concrete or wooden poles by means of a chain binder or a strap (Page 82), the auxiliary arm is used :

- To support one or more insulated by-pass jumpers with their protective tube held in place by the double clamps.
- To support a conductor in a conductor holder.

When the auxiliary arm is used on a square concrete pole, the saddle should be fitted with a wooden block (sold separately).

/ Areas of activity

 Electrical distribution

/ Technical specifications

- Tube diameter (mm) : 64
- Insulating length (mm) : 750
- Total length (mm) : 900
- WLL (daN) : 120
- Weight (Kg) : 4,7

/ Accessories

	Reference	Designation
	LW06-09-CALE	Adaptable wooden block.

/ Associated products

	Reference	Designation
	LW14-05	Product cleaning
	LW08-39	Roller driver support
	TC53	Insulated silicone-coated cloth
	LW06-04	Insulated by-pass jumpers
	LW08-38	Forked driver support