



See online
technical sheet

/ UNITAG
Phase tester for LV network



/ Technical specifications

- Battery type : 1,5V battery AAA (x2)
- Packaging : Textil bag
- Minimum temperature of use (C°) : 15
- Maximum temperature of use (C°) : 45

